



Aufstellungsanweisung Installation Instructions Notice de montage

MR 25-G 20L MR 25-G 25L MR 25-G 30L

MR 25-G 20L



MR 25-G 25L



TYP	BA I	DIL 0a-22	DIL 1-22	DIL 2(v)-22	GS 00	PKZM 3	N(ZM) 6-...	N(ZM) 9-...	NZMH 9-...	K 95/1	K 185/...	K 95/0	FZD
SDAINL 1-22 SDAINL 1-22/Z2-...	257	25	22/23										24
3 DIL 1-22 (V/G) 2 DIL 1-22 (V/G)/Z2...	257		3-5 26/27										
2 DIL 2(v)-22 (V/G) 2 DIL 2(v)-22 (V/G)/Z2-...	258			16/17									
DIUL 1	257		26/27										
DIUL 2(v)-22 (V/G) DIUL 2(v)-22 (V/G)/Z2-... DIUL 2(v)-22 sond 170 DIUL 2(v)-22 sond 170/Z2/Z2	258			16/17									
2 GS 00 (-160)	184				11/12								
3 PKZM 3-.../u(+HI 11) 2 PKZM 3-.../u+A(U)...(+HI...)	219					7-9 7/10							
3 PKZM 3-.../z (+HI 11) 2 PKZM 3-.../z+A(U)...(+HI...)	220					7-9 7/10							
2 PKZM 3-.../z+H3 (+HI 11) 2 PKZM 3-.../z+H3+A(U)...(+HI...)	221					7/10							
2 N(ZM) 6-...+H6	223						1/2						
3 N(ZM) 9-... (+2K 95/1) 3 N(ZM) 9-.../ZM 9 (+2K 95/1) 3 NZMH 9-.../ZM 9 (+2K 95/1)	224						18 18/19	20 20 18/19					
K 185/0	356									152/153 155/156			
K 185/O/N	356									151/153 154/156			
2 K 95/0	355											13/14	

TYP	BA I	DIL 3-22	SH 16 x 4 (8)	BT 0448	GS 0	GSTa 00	NZMH 4-...	NZM 6-...	ZW 6-...	K 300/0
2 DIL 3-22 (V/G) DIUL 3-22 DIUL 3-22-sond 170	259	20/21 20/21 20/21								
SH 16-4 (8) für RS 18-1 RS 27-1 RS 33-1 RGS 00-1	151 175		1							
3 SA-5 KL GS 0	155 184			12-14						
2 GSTa 00 (-160)	185				19					
2 NZMH 4	222 a						23/24			
2 NZM 6-.../ZM 6-...	223							10/11		
2 ZW 6-...	197								15/16	
K 300/0	356									17


Gewinde schneiden:
Filetage pour:
Thread for:

M4	M5	M5	M5	M4	M4	M5	M5	M5	M6	M5	M4
----	----	----	----	----	----	----	----	----	----	----	----

Gewinde schneiden:
Filetage pour:
Thread for:

M5	M5	M5	M6	M5	M4	M4	M4	M6
----	----	----	----	----	----	----	----	----

MR 25-G 30L



TYP	BA1	DIL 0a-22	DIL 2(v) -22	DIL 3-22	GSTa 0	GSTa 1	GS 1	NZMH 6-...	N(ZM) 11	N(ZM)11-.../ZM11	Z 4	K 150/1	FZD
SDAINL 2v-22 (/Z2-...) SDAINL 2 -22 (/Z2-...)	258	23	11/12 11-13										14 14
2 DIL 3-22 (/G)/Z2-... 2 DIL 3-22 (/G)/Z4-... DIUL 3-22/Z4-... DIUL 3-22-sond 170	259		1/2 1/2 1/2 1/2								3/4 3 3/4		
GSTa 0	185			18									
GSTa 1	185				24								
GS 1	184						19						
2 NZMH 6-.../ZM 6-...	223							5/6					
2 N(ZM)11-... (+2K150/1)	225								20			21/22	
2 N(ZM)11-.../ZM11 (+2K150/1)	225									20/25		21/22	

Gewinde schneiden: Fillage pour: Thread for:	M4	M5	M5	M5	M5	M5	M5	M4	M6	M6	M5	M5	M4
--	----	----	----	----	----	----	----	----	----	----	----	----	----