

Aufstellungsanweisung

Installation Instructions

Notice de montage


SEB 16...(-180°), 2 x SRB...(-180°) → GG-A 16...
 SE 12...(-180°), 2 x SR... (-180°) → GG-A 12...
 RS → GG-A

SEB 164 (-180°), 2xSRB...(-180°)

→ GG-A 16...4

SEB 166 (-180°), 2xSRB...(-180°)

→ GG-A 16...6



SE 124 (-180°), 2xSR...(-180°)



→ GG-A 12...4



SE 126 (-180°), 2xSR...(-180°)

→ GG-A 12...6

SE 128 (-180°), 2xSR...(-180°)

→ GG-A 12...8





GG-A	612	616	618	620	622
b	1056	1456	1656	1856	2056