




**Aufstellungsanweisung
Installation Instructions
Notice de montage**


(I) BLS + IH4 + TG → IVS




(I) BLS 65




(I) BLS 68




(I) BLS 612




(I) BLS 616




(I) BLS 620




(I) BLS 1216




(I) BLS 1220




(I) BLS 416




(I) BLS 420




(I) BLS 88



(I) BLS 812



(I) BLS 816



(I) BLS 820